

## **KIDD Bolt/Cocking Assembly Installation**

*Thank You for purchasing a KIDD CNC Bolt/Cocking Assembly.*

### **To remove bolt:**

1. Remove receiver from stock. Remove the trigger guard, receiver pins and the bolt buffer from receiver.
2. Slide Bolt back with the cocking handle. Pull the handle all the way to the rear of the receiver.
3. With your right index finger pull bolt back and lift up the bolt while releasing the cocking handle. You can also turn the receiver over for the bolt to fall out once you have slid the cocking handle all the way down.

### **To install the KIDD Bolt or KIDD Cocking Assembly:**

1. Slide spring over guide rod with pointed end down. Insert guide rod through the side of the receiver with the pointed end fitting into the bottom right groove. With the guide rod sticking out from the side, slide the cocking handle (slit facing up) onto the guide rod.
2. While pushing the spring down with the cocking handle, straighten the guide rod so that it's on the far right of the receiver. Be sure to slide the cocking handle all the way to the rear of the receiver.
3. Drop your new/old bolt in. (Try to drop the bolt in level so it slides in easier.) Wiggle the handle until the bolt drops in.
4. Slide bolt back up with the cocking handle to install your bolt buffer/pins.

Refer to the link below for a video showing removal and installation of the KIDD Bolt and Cocking assembly.

[http://www.coolguyguns.com/Cocking-Assembly\\_p\\_34.html](http://www.coolguyguns.com/Cocking-Assembly_p_34.html)